

MAINTENANCE REQUIREMENTS

8 SERIES - *Fire & Smoke Vent*



General Description

Airocle 8 Series low profile makes it suitable for installation across a wide range of roofs as it has minimal impact on a building's wind loading. Also with the ability of having either an automatic or manual over-ride, the 8 Series offers the option of an abundance of natural daylight while minimising heat loss and providing total weatherproofing on closure.

Inspection Requirements for both Static and Operable Ventilators

An inspection of the 8 Series Ventilator should occur every six months or a shorter interval should be used in marine or other corrosive environments and areas where atmospheric fallout occurs.

The inspection should cover, where applicable, the following;

- > Check vents for damage, wear, corrosion or residue build up.
- > Check and ensure that the vents and all components such as pulleys, hinges, latches, cables, struts, etc., are free from obstruction and capable of operation.
- > Check guides, bearings, springs and hinges are well lubricated.
- > Check actuators
- > Check battery dates and capacities
- > Check drain holes and internal drain channels are clear.
- > Check ram dust covers are in place.
- > Check for any mesh or bird wire damage.
- > Check for any damage to sealant used.
- > Any filters should be regularly checked for particle build up and cleaned every 6 months.

Cleaning Requirements for both Static and Operable Ventilators

Cleaning should be carried out every 6 months using the following procedure:

- > Cold water hose down of surface dirt to the inclination surfaces
- > Warm soapy detergent wash over all surfaces
- > Clean cold water hose down
- > Allow to air dry (do not allow to air dry before rinsing off the detergent)

The above process must be carried out at least once every 6 months. Should the Ventilators be 500 metres or less from salt water environment then the process should be carried out at least once every 3 months.

Please Note: If ventilators are used for Fire/Heat and Smoke ventilation, the goods must be serviced and maintained according to AS1851 every six months by a competent person. This is an essential Australian Standard compliance requirement. This will involve additional requirements to the above.

All service/maintenance must be carried out by an authorised technician and service records kept. Failure to do so may void your warranty.

For all necessary repairs call Airocle on 1800 805 062

15 Redbank Place
PO BOX 583 PICTON NSW 2571
service@airocle.com.au

